




Physikalisch-Technische Bundesanstalt
Braunschweig and Berlin
National Metrology Institute

Performance of the LDA Volumetric Flow Rate Standard Under Severely Disturbed Flow Conditions

Felix Heitmann, Jonas Steinbock and Markus Juling

Working Group 7.52
Volume Flow Rate



Motivation


- High T/P, disturbances and aging effects
- Elevated flow rate uncertainties in thermal power plants (up to 2 %)

Laser-optical flow rate measurement


- On-site calibration and monitoring
- Potential for process optimization
- Other high temperature applications
- Transfer Standard



Laser Doppler Anemometry (LDA)



Determination of the volumetric flow rate




Measurement
grid


Velocity profile

Volumetric flow
rate

LDA Volumetric Flow Rate Standard



Optical access




Heat water calibration rig

- Gravimetric method
- $T = 3$ to 90 °C
- $Q = 3$ to 1000 m³/h
- $U \leq 0.04$ % ($k=2$)




Asymmetric swirl disturbance generator

- Proposed by Tawackolian
- 5 angled blades
- Plate covering 7 % of area




Test parameters

- Configuration 1 – undisturbed:




- Configuration 2 – disturbed:




Nr.	T / °C	Re / 10 ³
1	20	50
2	20	100
3	20	450
4	60	450
5	60	945

Results – Undisturbed




Results – Fully developed turbulent flow




$$\Delta Q = 100 \frac{Q_{LDA} - Q_{ref}}{Q_{ref}}$$

max(ΔQ)	0.21 %
max(ΔQ _{LDA})	0.14 %

Results – Disturbed flow conditions



Results – Disturbed flow conditions




$$\Delta Q = 100 \frac{Q_{LDA} - Q_{ref}}{Q_{ref}}$$

max(ΔQ)	0.31 %
max(ΔQ_{LDA})	0.16 %

Summary

- Two measuring systems with good agreement between them ($\leq 0.16 \%$)
- Suitable for high temperature application
- Deviation to reference $\leq 0.31 \%$
- Small impact of severely disturbed flow condition ($\leq 0.1 \%$)





**Physikalisch-Technische Bundesanstalt
Braunschweig and Berlin**

Abbestraße 2-12
10587 Berlin

Felix Heitmann

Telefon: +49 303 481 7078

E-Mail: felix.heitmann@ptb.de

www.ptb.de